

Figure 1: Caption

# Determination of Moment of Inertia of a Flywheel

#### Aim

To determine the moment of inertia I of a flywheel about its axis of rotation.

# **Apparatus Required**

Flywheel, light string, known weight, stopwatch, meter scale or vernier calipers.

# Theory

When a torque  $\tau$  acts on a rotating body, the angular acceleration  $\alpha$  is given by

$$\tau = I\alpha$$

In this experiment, a light string is wound around the axle of the flywheel. A small mass m is attached to the free end of the string. When released, the mass descends with linear acceleration a, and the flywheel acquires angular acceleration  $\alpha = \frac{a}{r}$ , where r is the radius of the axle. The tension T in the string provides the torque on the flywheel:

$$\tau = Tr = I\alpha$$

For the falling mass,

$$mg - T = ma$$

Eliminating T and substituting  $a = r\alpha$ , we have

$$mgr - mr^{2}\alpha = I\alpha$$

$$\Rightarrow I = \frac{mgr - mr^{2}\alpha}{\alpha} = mr\left(\frac{g - r\alpha}{\alpha}\right)$$

$$I = mr\frac{(g - r\alpha)}{\alpha}$$

The angular acceleration  $\alpha$  is determined from the time t taken by the falling mass to unwind the string through n revolutions before detachment:

$$\theta = 2\pi n = \frac{1}{2}\alpha t^2$$

$$\Rightarrow \boxed{\alpha = \frac{4\pi n}{t^2}}$$

Substitute this  $\alpha$  in the above expression to obtain I.

If the frictional torque is small, it may be neglected in the first approximation.

#### **Procedure**

- 1. Measure the radius r of the flywheel axle using a vernier caliper or meter scale.
- 2. Wind a light, inextensible string around the axle and attach a known mass m to its free end.
- 3. Allow the mass to fall through n revolutions and record the time t taken for the fall.
- 4. Repeat the experiment for different values of m or n.
- 5. For each observation, calculate  $\alpha = \frac{4\pi n}{t^2}$ .
- 6. Compute  $I = mr \frac{(g r\alpha)}{\alpha}$  for each trial.
- 7. Find the mean value of I.

### Observations

Sl. No.	m (kg)	n	t (s)	$\alpha = \frac{4\pi n}{t^2} \; (\mathrm{rad/s^2})$	$I = \frac{mr(g-r\alpha)}{\alpha}$ (kg m <sup>2</sup> )
1					
2					
3					
4					
5					
6					

# **Calculations**

$$\alpha = \frac{4\pi n}{t^2}$$
 
$$I = mr \frac{(g - r\alpha)}{\alpha}$$
 
$$I_{\text{mean}} = \frac{\sum I_i}{N}$$

#### Result

$$I = \dots$$
 kg m<sup>2</sup>

The moment of inertia of the flywheel about its axis is determined using the above relation.

#### **Precautions**

- 1. The string should be light, inextensible, and wound uniformly without overlap.
- 2. The flywheel axle should be well-lubricated and free from wobble.
- 3. The falling weight should be just sufficient to overcome friction.
- 4. Start and stop the stopwatch accurately.
- 5. Repeat the readings for consistency.

#### Sources of Error

- Error in measurement of radius of the axle.
- Reaction time error in stopwatch operation.
- Neglecting the effect of frictional torque and air resistance.
- Non-uniform winding of the string.

# 1 Error Analysis

Note that  $I_{mean} = \overline{I_i}$ 

Sl. No.	$I_i$	$\overline{(I_i-\overline{I_i})^2}$	$\sqrt{\overline{(I_i - \overline{I_i})^2}}$
1			
2			
3			
4			
5			
6			

# Conclusion

The experiment verifies the relationship between the torque and angular acceleration of a rotating flywheel and allows the determination of its moment of inertia.